



shower_discharge

v1.01

Assemble with glue.

Cut it in a black thin cardboard and glue it in the bottom of the shower tray

2014/07/17

www.ldworkshop.fr

