



shower\_discharge

v1.01

Assemble with glue.

Cut it in a black thin cardboard and glue it in the bottom of the shower tray

2014/07/17

[www.ldworkshop.fr](http://www.ldworkshop.fr)

